


Space for logo if required

# SET1E User Instructions



Your clock/programmer controls your heating by allowing you to decide when and for how long your heating will be on.

## Resetting the Unit

If the SET1E is disconnected from the mains it will switch off the system. It will keep your programme time and settings for up to 10 hours. After 10 hours the display will go blank and the unit will lose its settings.

When mains power is restored, you will need to reset the unit. To do this:

- move the slide switch to **SET TIME** position (**Fig.1**)
- gently press something non-metallic (i.e a matchstick) through the round hole at the base of the switch to reset

This reinstalls the factory pre-set programme and sets the time of day to noon.

## Setting the Clock

Move the slider to **SET TIME** position (**Fig.1**)

Use ◀ and ▶ keys to set the correct time (**Fig.2**)

## Programming Event Times

When the time settings are complete you can programme the times at which you want the programmer to come on and go off. You can have 2 ONs and 2 OFFs per day.

- Move the slider to the **1st ON** position (**Fig.3**) and use ◀ and ▶ keys (**Fig.2**) to set the time you want the programmer to first come on
- Move the slider to the **1st OFF** position (**Fig.4**) and use ◀ and ▶ keys (**Fig.2**) to set the time you want the programmer to first go off
- Repeat for **2nd ON** and **2nd OFF** (**Fig.5**)

Remember to return the slider switch to the **RUN** position (**Fig.6**) after programming

Fig.1




Fig.2



Fig.3




Fig.4




Fig.5





Fig.6



## Temporary User Overrides

The SET1E has two convenient overrides which can be selected to temporarily override the set programme. This will only work when the slider switch is in the **RUN** position (**Fig.6**) and will automatically cancel at the start of the next programmed event.


### Advance

- Press the **ADVANCE** button (**Fig.7**) once to advance to the next programmed event
- If the system is on it will go off. If it is off it will come on
- A bar on the left of the LCD will remind you that you have selected **ADVANCE**
- To cancel the override, press the **ADVANCE** button again (**Fig.7**)


### 1 Hour Extra

- Press **+1 HOUR** button (**Fig.8**) once if you need an extra hour of operation
- If the system is off it will come on. If it is already on it will add an extra hour so the system stays on for an extra hour
- A bar on the right of the LCD will remind you that you have selected **+1 HOUR**
- To cancel the override, press the **+1 HOUR** button again (**Fig.8**)


**Fig.7**




**Fig.8**



**Fig.9**



**Fig.10**



## Manual Switch Settings (Fig.9)

A manual rocker switch lets you make more permanent overrides for the heating:

- **Off** - the heating is manually switched OFF and will stay off until you change the position of the switch
- **Timed** - the heating will come on and go off at the times you have programmed, plus any temporary overrides
- **Constant** - the heating will come on manually and stay on constantly until you change the position of the switch

## Indicator Lights (Fig.10)

A red light will be lit whenever the system is switched on